

11. Do not apply hot wax near eyes or other heat-sensitive areas , or to any skin injuries.
12. Allow heater to cool fully before handling, cleaning and storing.
13. The wax heater must be placed on a level surface during use.
14. Do not let cord hang over the edge of a table or counter where it can be pulled off by children or tripped over accidentally.
15. Unplug from outlet when not in use.
16. Before using, test hot wax on a small area of skin for temperature and possible skin reactions.

**Safety notes**

1. Do not immerse the unit in water, or use it in an area where it could be splashed.
2. Always unplug the unit when not in use.
3. The heater element is capable of producing a very high temperature, therefore, NEVER move the heater whilst it contains hot wax.

**Cleaning**

1. The heater should only be cleaned with a recognised wax equipment cleaner specifically formulated for the removal of wax as this will maintain the heater in optimum condition if used regularly.
2. Never use Surgical Spirit for cleaning, as this may erode the plastic casing of the heater and cause damage.
3. Do not use other solvents as they could damage the heater and may produce toxic fumes when the heater is operating.
4. Wax spilled onto the heater casing should be removed as soon as possible. If the wax is allowed to harden removal is more difficult.
5. It is especially important to keep the on/off switch and the temperature regulator control dial free of wax.

SalonSERVE®



**1000cc and 500cc  
Twin Wax Heater**

**Product code: W001**

**Careline: 01933 410022  
www.salonservice.com**

**Super Compact Wax Heater  
1000cc and 500cc. Product code: W001**

The Wax heater has a heat chamber for use with wax placed directly into the insert provided. Alternatively, wax in plastic pots or metal cans can be inserted directly into the heater well.

The Wax heater has a wide range of operating temperatures available, designed to suit all types of wax - strip and hard wax.

The Wax heater is moulded in high resistant, durable materials with accurate controls and settings for simple operation and ease of use.

**Features and functions**

- 1000cc and 500cc insert capacity
- Thermostatically controlled
- Moulded in durable heat resistant material



**IMPORTANT SAFETY INSTRUCTIONS**

When using electrical appliances, basic safety precautions should always be taken, including the following - DANGER - TO REDUCE THE RISK OF ELECTRIC SHOCK:

1. Always unplug this wax heater immediately after using.
2. Never place or store wax heater where it can fall or be pulled into a tub or sink.
3. DO NOT place or drop into water or other liquid.
4. Never reach for a wax heater that has fallen into water. Unplug immediately

**Instructions for use**

1. Remove lid.

2. Fill the insert with the wax of your choice or place a wax pot into the well.

3. Plug into mains power supply and press on/off switch.

4. Move regulator temperature control clockwise to a setting suitable for the type of wax used. The thermostat indicator light will remain illuminated until the required temperature is reached. Thereafter the thermostat will automatically switch the heater off/on to maintain the chosen heat setting.

5. To increase temperature rotate regulator control clockwise. To reduce temperature rotate regulator control anti-clockwise.

**Recommendation**

To avoid loss of profitable working time, we suggest that the heater is switched on approx. 30 minutes before treatments are due to commence to ensure that wax has reached the correct working temperature.

**WARNING**

To reduce the risk of burns electrocution, fire or injury to persons:

1. Never leave heater unattended when plugged into mains power.
2. This heater should not be used by, on ,or near children.
3. Use this heater only for its intended use as described in the operating instructions.
4. Do not use attachments not recommended.  
Never operate this heater if it has a damaged power cord or plug, if it is not working properly, if it has been dropped or damaged ,or dropped into water.
5. Keep the power cord away from hot or heated surfaces. Do not wrap the cord around the heater. This could cause the cord to wear prematurely and rupture.
6. Never place the heater on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint ,wax, hair and all other debris.
7. Do not use outdoors or operate where aerosol (spray) products are being used.
8. Do not use an extension cord with this heater.