



3 Section Electric Couch SEQ3357A

Thank you for purchasing the SEQ3357A.
Please read the user manual carefully before use.

1. About This Manual


This manual shall only be used for the reference of operation of this particular model. If the manual is used for other purposes, we will not undertake any according consequences and responsibility. All information of this manual shall be protected by copyright and shall not be copied and translated in any part of this specification without the written consent of manufacturer.

2. Warning

- Power must be turned off when changing electrical components, and when cleaning or servicing the couch.
- The plug must be plugged into an outlet that is properly installed and grounded, to prevent the risk of fire and electric shock.
- Do not stand on this equipment.
- Please keep children away from this equipment.
- Please adjust the backrest to the highest position after use.
- Do not place the equipment near water to avoid electric shock or electrical failure. Keep controller away from water.
- Please contact distributors, service centre or related personnel with appropriate skills or expertise for repairing.
- For use by trained professionals only.

3. Precautions

- This product should be used by an experienced person who must be familiar with the product structure, performance and instructions. And make the regular maintenance work.
- Read this manual carefully before installation, operation and adjustment. And please keep it well.
- This product shall not be used for single side or single point loading work.
- Comply with safety operation rules, product shall not be overloading, and to ensure that the product safety protection equipment is complete and reliable, eliminates unsafe factors on time.
- Tighten bolts and nuts regularly to avoid failure caused by loose, sliding, vibration and falling off.
- During the maintenance, the operator shall not disassemble any parts of the bed at will.
- This product is not allowed to operate when it's with fault. If abnormal phenomenon or abnormal sound is found, it must be stopped for inspection immediately, and work can be resumed after troubleshooting.
- The operator must be familiar with the precautions described in each section of the manual to ensure the safety of person and product.
- This product is equipped with a three-wire power cord. The power cord must be plugged into a three-hole outlet which is properly installed and grounded. This is not only to prevent the risk of electric shock, but ensure product can work properly.
- Please operate the product strictly accordance with the warning label stamped on it.
- While controlling the lifting, the button must be pressed continuously until the product in a suitable position.
- Please pay attention that the continuous working times should be Max. 2Min. ON ; 18Min. OFF, when operating the motor.
- Maintenance should be processed by trained professionals.
- After every treatment, please only use neutral solution to clear the dust or stains on the product.
- For products with heating function, the max surface temperature of upholstery does not exceed 45°C.
- When adjusting each part, please keep your hands, feet and head away from the position indicated by the arrow. (As shown in the photo)




4. Installation

1. Put the product to a proper location, according to the overall layout, the daylighting or artificial lightings and operation condition of the salon's or the home. And keep it in the clean, dry and cool environment.
2. Open the packing carton to check if the product is intact and whether the accessories or spares are complete. Please contact distributor or us if there's any problem.

3. Installation


Place the product to the proper position. Please note that it is unnecessary to install extra screw on the floor to fasten the bed, because the original design has taken the stability into consideration. But please ensure the product is placed on a firm and flat ground, so as to prevent any accident. If the product rotates or slant due to rough ground, please adjust the four pieces of plastic feet (M10×30) and nuts (M10) by hexagon open-end wrench, which are fasten on the bottom panel, so as to ensure the product is stable.

4. Connect the plug of product with power supply properly. (As shown in the photo)



5. Structure of products


- This product consists of control box, motor, hardware, plastic parts and leather. Among them, the control box is controlling the operation of the motors and the hand controller.
- This product includes angle adjustment of the backrest, seatrest and footrest ,also the whole bed up & down movement .(As shown in the photo)



- ① angle adjustment of the backrest (manual adjustment)
- ② lifting adjustment
- ③ angle adjustment of the footrest (manual adjustment)

6. Operation Instruction

Standard Configuration
(Hand Controller)




No.	Description	Operation
3	Lifts up	Whole chair/table lifts up smoothly by pressing the button.
4	Lifts down	Whole chair/table lifts down smoothly by pressing the button.

IMPORTANT:




It is very important that the top part of the couch is placed the correct way around onto the base.

If the top part is installed incorrectly, this may result in damage to your couch. Please refer to the images below to see the correct installation.



7. Technical Parameters

Power	AC 100-120V or AC 220-240V or AC 100-240V, 50/60Hz
Maximum Power	300W
Environment Temperature	0℃ ~ + 40℃
Relative Humidity	30% ~ 90%
Lifting Rated Load	175kg
Package Size	2217/2217A :178×65×23cm(TOP) 92×56×48cm(BASE) 2217B/2217C/2217D/2217E/2217F :145×65×69cm 2217H :145×65×63.5cm




8. Maintenance

1. After every treatment, please only use neutral solution to clear the dust, stains on leather, metal part or other parts. Disinfecting solution like alcohol, acid or alkaline solution are forbidden.
This is to prevent the lifetime of the components from being shortened.
2. Please lubricate the moving parts regularly (once a year)

9. Circuit Diagram

2217 / 2217A / 2217B / 2217C



10. Troubleshooting

The Fault Phenomenon	Reason	Solution
Motor can't work normally	1. The power cord is unconnected or not plugged well.	1. Connect the power cord or plug it well.
	2. Poor quality of the hand controller or foot controller.	2. Replace the hand controller or foot controller.
	3. Poor quality of the control box.	3. Please contact maintenance center or supplier for troubleshooting.
	4. Repture of motor tail.	
	5. Motor was damaged.	
Abnormal Sound	1. The rotating parts are short of lubricating oil.	1. Add lubricating oil.
	2. Rotating positions (such as hinge, POM sets, gas lift) are short of lubricating oil.	2. Add lubricating oil.
	3. Motor quality problems.	3. Replace the motor.

If problem is still not solved after above operations, please contact maintenance center or supplier to solve it.



Do not dispose of old or defective appliances in domestic garbage; this should only be done through public collection points.

▲ Please check the product specification before use. This manual is for reference only. Specifications are subject to change without prior notice.